



Item

AX-88 Laser Pinhole Drilling Unit

Article Number

MP05001

Certification

ISO9001:2000 Approved

Purpose

The unit is used in model-making, it provides a simple way to fabricate precise parallel drill channels.

Description

This AX-88 Laser Pinhole Drilling Unit features high RPM, low noise, and easy operations. The laser beam positioning system ensures high precision operations. The drilling depth can be adjusted within 0.15mm. The travel switch allows the motor to be turned on when the worktable is being pressed, which helps to increase its lifespan.

Technical Data

Power Supply: 220V/110V 50/60Hz

Power Consumption: 150W

Rotational Speed: 2,800RPM

Drilling Depth: 0~12mm (Adjustable)

Dimensions: 39cm x 18cm x 18cm (H W D)

Shipping Dimensions: 47cm x 18cm x 25cm (H W D)

Overseas Marketing:

Add: 6B-101, No.15 Rongyuan Road, Huayuan New-Tech Industrial Park, Tianjin, China, 300384

Tel: +86 (0)22 23859319/23859320 (English Service)

Fax: +86 (0)22 23859321

E-mail: richard@tjax.com.cn, tjaxyl@hotmail.com



Aixin Medical Equipment Co.,Ltd. China
中國天津。愛鑫醫療設備有限公司

Weight: 17kg

Parts Included

Machine×1

Manual×1

Power Cord×1

Fuse×2

Drill×1

Overseas Marketing:

Add: 6B-101, No.15 Rongyuan Road, Huayuan New-Tech Industrial Park, Tianjin, China, 300384

Tel: +86 (0)22 23859319/23859320 (English Service)

Fax: +86 (0)22 23859321

E-mail: richard@tjax.com.cn, tjaxyl@hotmail.com